



BLACK HORSE OFF ROAD®

Installation Instructions

Workhorse Auto Safe

Part# ASJW01 Fits: - JEEP WRANGLER 2018-2022

Hardware

- 4 pcs Self-Tapping Screws
- 4 pcs Acorn Nuts

Tools Needed:

- Open-end Wrench (or socket wrench)
- Phillips Screwdriver





Installing the Safe

STEP 1 Empty the armrest box including the factory mat at the bottom of the console.

STEP 2 Place the **Top Panel** into the armrest box.

STEP 3 Open the **Lid** and put the **Side Panels** under the top panel. Please note, the side panels are different. Locate the marks both on the top and side panels and match them. Check that the screws of the top panel are inserted into the holes in the side panels.

STEP 4 Use the Wrench to tighten the 4 Acorn nuts to the screws of the Top Panel.

STEP 5 Use the Screwdriver to tighten the Self Tapping Screws into the bottom of the safe.

STEP 6 Replace the padding in the floor of the safe.

Setting the Combination

The factory preset combination is 0-0-0-0

Please keep the safe door open when changing the combination.

To change the combination, insert the coding pin provided into the hole in the side of the lock.



Remove the coding pin to lock in the combination. Test the lock operation before closing the safe door.

Please note: The combination can only be changed again by setting the saved combination and inserting the pin. Please record the combination on the card provided and keep in a safe place.

Keep the pin in the safe in case you wish to change the combination.